


FERRONI

MAGIC SPAVENTAPASSERI E DISSUASORI MAGIC SCARECROW AND SOUND DETERRENTS



MAGIC SPAVENTAPASSERI E DISSUASORI ELETTRONICI MAGIC ELECTRONIC SCARECROW AND SOUND DETERRENTS



Lo spaventapasseri assicura una protezione da tutti gli animali (uccelli, roditori, selvaggina) a raccolti e colture specializzate (frutteti, vigneti, orti, coltivazioni di riso, ecc.), protegge una superficie di oltre 4 ettari. L'apparecchio funziona con gas GPL propano o butano, una bombola da 13 kg produce oltre 30.000 detonazioni. Il sistema di accensione funziona elettronicamente, alimentato da una batteria a 12 V (non inclusa). Le detonazioni possono essere regolate ad intervalli da 1 a 20 minuti. Il modello con fotocellula crepuscolare si accende automaticamente con la luce del giorno e si spegne al tramonto, il modello con detonazione multipla permette di non far abituare l'animale al rumore.



The scarecrow ensures constant protection from all animals (birds, rodents, game) for specialised harvests and crops (orchards, vineyards, vegetable gardens, rice crops, etc.). It protects an area of over 4 hectares. The appliance works with propane or butane LPG gas. A 13 kg gas cylinder produces over 30,000 detonations. The ignition system works electronically, powered by a 12 V battery (not included). The detonations can be adjusted at intervals from 1 minute to 20 minutes. The model with twilight photocell turns on automatically with daylight and turns off at sunset, the model with multiple detonation allows the animal to not get used to the noise.



Il dissuasore sonoro allontana volatili come cornacchie, storni, corvi, assicurando una costante protezione a raccolti e colture, grazie alla riproduzione di versi degli uccelli predatori. Il MAGIC-SOUND funziona collegandolo ad una batteria a 12V, tramite il dispositivo crepuscolare si ha una accensione automatica al nascere del giorno.



The sound deterrent drives away birds such as crows, starlings and ravens, ensuring constant protection for specialised harvests and crops, thanks to the reproduction of songs of predatory birds. The MAGIC SOUND works simply by connecting it to a 12 V battery and a twilight device automatically turns it on when the day dawns.



Codice Code	Modello Model	Voltaggio Voltage	min. Ah Batteria min. AH Battery	Decibel Decibel	Dimensioni Dimensions	Peso Weight
0550.1401	MAGIC con detonazione singola / with single detonation	12 V	30 Ah	140	92x45x26 cm	9 kg
0550.1402	MAGIC F/C con detonazione singola e fotocellula crepuscolare / with single detonation and twilight photocell	12 V	30 Ah	140	92x45x26 cm	9 kg
0550.1404	MAGIC 3/C con detonazione multipla e fotocellula crepuscolare / with multiple detonation and twilight photocell	12 V	30 Ah	140	92x45x26 cm	9 kg
0550.1405	MAGIC 3/C/S con detonazione multipla / with multiple detonation	12 V	30 Ah	140	92x45x26 cm	9 kg
0560.1501	MAGIC SOUND	12 V	20 Ah	120	15x15x20 cm	1 kg



FERRONI s.r.l.

